


GUITAR MANIA

Guitar Controller Setup and Usage Instructions

Congratulations on your purchase of a Guitar Mania Guitar Controller! Please read the following instructions carefully before attempting to use the controller.

INTRODUCTION



*The actual style of the guitar controller may be different from the example shown above.

- **START** button : Pause
- **SELECT** button : Activate Star Power
- **GREEN** button : Activate the Green note / Confirm
- **RED** button : Activate the Red note / Cancel
- **YELLOW** button : Activate the Yellow note
- **BLUE** button : Activate the Blue note
- **ORANGE** button : Activate the Orange note
- **STRUM BAR** : Move the Strum Bar up or down to activate the color buttons and to navigate the menu
- **Whammy Bar** : Press the bar down to alter the sound of the song
- **Shake Sensor** : Located inside the casing at the base of the neck. It is used to activate the Star Power. To activate, shake the controller up or down.

FOR THE WIRED CONTROLLER

Step 1. Connect the PS2 connector on the guitar to the controller port 1 or 2 of your Sony PlayStation 2 console and start the game.

Please refer to the Guitar Hero manual for further instructions.

WARRANTY

- This product comes with three (3) months of warranty from the date of purchase against manufacturing defect.

For further information on the warranty and to activate the warranty, please register the product at <http://www.theantcommandos.com/warranty>.

NOTICE

- This product is made for indoor use only.
- Keep the product at room temperature.
- Product contains electrical components; please keep it away from moisture.
- Modifying or disassembling the controller in any way will void the warranty.
- The controller must be used with care to avoid injury. TAC will not be liable for injury resulting from the improper use of the controller.
- Do not use any chemical compound to clean the product.